

Manufacturer	Family	Model name	フラグ
Acer	Aspire	Aspire 1400 (AS1400)	G
Acer	Aspire	Aspire 3410 (AS3410)	G
Acer	Aspire	Aspire 3690 (AS3690)	G
Acer	Aspire	Aspire 3810TZ (AS3810TZ)	G
Acer	Aspire	Aspire 3820TG (AS3820TG)	G
Acer	Aspire	Aspire 4250 (AS4250)	G
Acer	Aspire	Aspire 4315 (AS4315)	G
Acer	Aspire	Aspire 4339 (AS4339)	G
Acer	Aspire	Aspire 4535 (AS4535)	G
Acer	Aspire	Aspire 4552 (AS4552)	G
Acer	Aspire	Aspire 4720 (AS4720)	G
Acer	Aspire	Aspire 4733Z (AS4733Z)	G
Acer	Aspire	Aspire 4738Z (AS4738Z)	G
Acer	Aspire	Aspire 4741 (AS4741)	G
Acer	Aspire	Aspire 4745 (AS4745)	G
Acer	Aspire	Aspire 4810T (AS4810T)	G
Acer	Aspire	Aspire 4830T (AS4830T)	G
Acer	Aspire	Aspire 5050 (AS5050)	G
Acer	Aspire	Aspire 5251 (AS5251)	G
Acer	Aspire	Aspire 5315 (AS5315)	G
Acer	Aspire	Aspire 5333 (AS5333)	G
Acer	Aspire	Aspire 5336 (AS5336)	G
Acer	Aspire	Aspire 5516 (AS5516)	G
Acer	Aspire	Aspire 5530 (AS5530)	G
Acer	Aspire	Aspire 5535 (AS5535)	G
Acer	Aspire	Aspire 5541 (AS5541)	G
Acer	Aspire	Aspire 5552 (AS5552)	G
Acer	Aspire	Aspire 5570 (AS5570)	G
Acer	Aspire	Aspire 5720Z (AS5720Z)	G
Acer	Aspire	Aspire 5733 (AS5733)	G
Acer	Aspire	Aspire 5735 (AS5735)	G
Acer	Aspire	Aspire 5738 (AS5738)	G
Acer	Aspire	Aspire 5738PG (AS5738PG)	G
Acer	Aspire	Aspire 5740 (AS5740)	G
Acer	Aspire	Aspire 5741Z (AS5741Z)	G
Acer	Aspire	Aspire 5742Z (AS5742Z)	G
Acer	Aspire	Aspire 5750Z (AS5750Z)	G
Acer	Aspire	Aspire 5820T (AS5820T)	G
Acer	Aspire	Aspire 6530 (AS6530)	G
Acer	Aspire	Aspire 7250 (AS7250)	G
Acer	Aspire	Aspire 7540 (AS7540)	G
Acer	Aspire	Aspire 7730 (AS7730)	G
Acer	Aspire	Aspire 7735Z (AS7735Z)	G
Acer	Aspire	Aspire 7739 (AS7739)	G
Acer	Aspire	Aspire 7740G (AS7740G)	G
Acer	Aspire	Aspire 7745 (AS7745)	G
Acer	Aspire	Aspire E1-531	G
Acer	Aspire	Aspire M3	G
Acer	Aspire	Aspire M5-481T	G
Acer	Aspire	Aspire S3	G
Acer	Aspire	Aspire S7-191	G
Acer	Aspire	Aspire Timeline 3410 (AS3410)	G
Acer	Aspire	Aspire Timeline 4810T (AS4810T)	G
Acer	Aspire	Aspire Timeline X 3830T (AS3830T)	G
Acer	Aspire	Aspire V3-571	G
Acer	Aspire	Aspire V5-171	G

Acer	Aspire	Aspire V5-531P	G
Acer	Ferrari	Ferrari 1000 (F1000)	G
Acer	TravelMate	TravelMate 2310 (TM2310)	G
Acer	TravelMate	TravelMate 4720 (TM4720)	G
Acer	TravelMate	TravelMate 4740Z (TM4740Z)	G
Acer	TravelMate	TravelMate 5330 (TM5330)	G
Acer	TravelMate	TravelMate 5360 (TM5360)	G
Acer	TravelMate	TravelMate 5542 (TM5542)	G
Acer	TravelMate	TravelMate 5740 (TM5740)	G
Acer	TravelMate	TravelMate 5760 (TM5760)	G
Acer	TravelMate	TravelMate 6293 (TM6293)	G
Acer	TravelMate	TravelMate 6594 (TM6594)	G
Acer	TravelMate	TravelMate 7730 (TM7730)	G
Acer	TravelMate	TravelMate 8100 (TM8100)	G
Acer	TravelMate	TravelMate 8372 (TM8372)	G
Acer	TravelMate	TravelMate 8472 (TM8472)	G
Acer	TravelMate	TravelMate 8572 (TM8572)	G
Acer	eMachines	eMachines D443	G
Acer	eMachines	eMachines D620	G
Acer	eMachines	eMachines E440	G
Acer	eMachines	eMachines E520	G
Acer	eMachines	eMachines E528	G
Acer	eMachines	eMachines E625	G
Acer	eMachines	eMachines E725	G
Acer	Aspire	Aspire 1551 (AS1551)	G
Acer	Aspire	Aspire 3620 (AS3642)	G
Acer	Aspire	Aspire 3750 (AS3750)	G
Acer	Aspire	Aspire 3820 (AS3820)	G
Acer	Aspire	Aspire 3830T (AS3830T)	G
Acer	Aspire	Aspire 4252 (AS4252)	G
Acer	Aspire	Aspire 4330 (AS4330)	G
Acer	Aspire	Aspire 4520 (AS4520)	G
Acer	Aspire	Aspire 4540 (AS4540)	G
Acer	Aspire	Aspire 4553 (AS4553)	G
Acer	Aspire	Aspire 4730Z (AS4730Z)	G
Acer	Aspire	Aspire 4736Z (AS4736Z)	G
Acer	Aspire	Aspire 4739 (AS4739)	G
Acer	Aspire	Aspire 4743 (AS4743)	G
Acer	Aspire	Aspire 4745Z (AS4745Z)	G
Acer	Aspire	Aspire 4810TZ (AS4810TZ)	G
Acer	Aspire	Aspire 4930 (AS4930)	G
Acer	Aspire	Aspire 5100 (AS5100)	G
Acer	Aspire	Aspire 5252 (AS5252)	G
Acer	Aspire	Aspire 5320 (AS5320)	G
Acer	Aspire	Aspire 5334 (AS5334)	G
Acer	Aspire	Aspire 5349 (AS5349)	G
Acer	Aspire	Aspire 5517 (AS5517)	G
Acer	Aspire	Aspire 5532 (AS5532)	G
Acer	Aspire	Aspire 5536 (AS5536)	G
Acer	Aspire	Aspire 5542 (AS5542)	G
Acer	Aspire	Aspire 5553 (AS5553)	G
Acer	Aspire	Aspire 5570Z (AS5570Z)	G
Acer	Aspire	Aspire 5730Z (AS5730Z)	G
Acer	Aspire	Aspire 5733 (AS5733Z)	G
Acer	Aspire	Aspire 5735Z (AS5735Z)	G
Acer	Aspire	Aspire 5738DG (AS5738DG)	G
Acer	Aspire	Aspire 5738Z (AS5738Z)	G

Acer	Aspire	Aspire 5740G (AS5740G)	G
Acer	Aspire	Aspire 5742 (AS5742)	G
Acer	Aspire	Aspire 5745 (AS5745)	G
Acer	Aspire	Aspire 5810T (AS5810T)	G
Acer	Aspire	Aspire 5830T (AS5830T)	G
Acer	Aspire	Aspire 6920 (AS6920)	G
Acer	Aspire	Aspire 7530 (AS7530)	G
Acer	Aspire	Aspire 7551 (AS7551)	G
Acer	Aspire	Aspire 7730Z (AS7730Z)	G
Acer	Aspire	Aspire 7736 (AS7736)	G
Acer	Aspire	Aspire 7739Z (AS7739Z)	G
Acer	Aspire	Aspire 7741 (AS7741)	G
Acer	Aspire	Aspire 7745Z (AS7745Z)	G
Acer	Aspire	Aspire E1-571	G
Acer	Aspire	Aspire M3-581T	G
Acer	Aspire	Aspire One 721 (AO721)	G
Acer	Aspire	Aspire S3-391	G
Acer	Aspire	Aspire S7-391-F74Q	G
Acer	Aspire	Aspire Timeline 3810 (AS3810T)	G
Acer	Aspire	Aspire Timeline 5810T (AS5810T)	G
Acer	Aspire	Aspire TimelineX 3820T (AS3820T)	G
Acer	Aspire	Aspire V3-571G	G
Acer	Aspire	Aspire V5-431	G
Acer	Aspire	Aspire V5-571P	G
Acer	Ferrari	Ferrari 1100 (F1100)	G
Acer	ICONIA	ICONIA W700-2	G
Acer	TravelMate	TravelMate 2420 (TM2420)	G
Acer	TravelMate	TravelMate 4730 (TM4730)	G
Acer	TravelMate	TravelMate 4750 (TM4750)	G
Acer	TravelMate	TravelMate 5335 (TM5335)	G
Acer	TravelMate	TravelMate 5520 (TM5520)	G
Acer	TravelMate	TravelMate 5720 (TM5720)	G
Acer	TravelMate	TravelMate 5742 (TM5742)	G
Acer	TravelMate	TravelMate 6291 (TM6291)	G
Acer	TravelMate	TravelMate 6492 (TM6492)	G
Acer	TravelMate	TravelMate 6595T (TM6595T)	G
Acer	TravelMate	TravelMate 7740 (TM7740)	G
Acer	TravelMate	TravelMate 8331 (TM8331)	G
Acer	TravelMate	TravelMate 8372T (TM8372T)	G
Acer	TravelMate	TravelMate 8481 (TM8481)	G
Acer	TravelMate	TravelMate 8572T (TM8572T)	G
Acer	eMachines	eMachines D525	G
Acer	eMachines	eMachines D732	G
Acer	eMachines	eMachines E442	G
Acer	eMachines	eMachines E525	G
Acer	eMachines	eMachines E529	G
Acer	eMachines	eMachines E627	G
Acer	eMachines	eMachines E732	G
Acer	Aspire	Aspire 1640 (AS1640)	G
Acer	Aspire	Aspire 3680 (AS3680)	G
Acer	Aspire	Aspire 3810T (AS3810T)	G
Acer	Aspire	Aspire 3820T (AS3820T)	G
Acer	Aspire	Aspire 3935 (AS3935)	G
Acer	Aspire	Aspire 4253 (AS4253)	G
Acer	Aspire	Aspire 4333 (AS4333)	G
Acer	Aspire	Aspire 4530 (AS4530)	G
Acer	Aspire	Aspire 4551 (AS4551)	G

Acer	Aspire	Aspire 4560 (AS4560)	G
Acer	Aspire	Aspire 4732Z (AS4732Z)	G
Acer	Aspire	Aspire 4738 (AS4738)	G
Acer	Aspire	Aspire 4739Z (AS4739Z)	G
Acer	Aspire	Aspire 4743Z (AS4743Z)	G
Acer	Aspire	Aspire 4750 (AS4750)	G
Acer	Aspire	Aspire 4820T (AS4820T)	G
Acer	Aspire	Aspire 4937 (AS4937)	G
Acer	Aspire	Aspire 5250 (AS5250)	G
Acer	Aspire	Aspire 5253 (AS5253)	G
Acer	Aspire	Aspire 5330 (AS5330)	G
Acer	Aspire	Aspire 5335 (AS5335)	G
Acer	Aspire	Aspire 5515 (AS5515)	G
Acer	Aspire	Aspire 5520 (AS5520)	G
Acer	Aspire	Aspire 5534 (AS5534)	G
Acer	Aspire	Aspire 5538 (AS5538)	G
Acer	Aspire	Aspire 5551 (AS5551)	G
Acer	Aspire	Aspire 5560 (AS5560)	G
Acer	Aspire	Aspire 5715Z (AS5715)	G
Acer	Aspire	Aspire 5732Z (AS5732Z)	G
Acer	Aspire	Aspire 5734Z (AS5734Z)	G
Acer	Aspire	Aspire 5736Z (AS5736Z)	G
Acer	Aspire	Aspire 5738G (AS5738G)	G
Acer	Aspire	Aspire 5738ZG (AS5738ZG)	G
Acer	Aspire	Aspire 5741 (AS5741)	G
Acer	Aspire	Aspire 5742G (AS5742G)	G
Acer	Aspire	Aspire 5750 (AS5750)	G
Acer	Aspire	Aspire 5810TZ (AS5810TZ)	G
Acer	Aspire	Aspire 5920 (AS5920)	G
Acer	Aspire	Aspire 6935 (AS6935)	G
Acer	Aspire	Aspire 7535 (AS7535)	G
Acer	Aspire	Aspire 7560 (AS7560)	G
Acer	Aspire	Aspire 7735 (AS7735)	G
Acer	Aspire	Aspire 7736Z (AS7736Z)	G
Acer	Aspire	Aspire 7740 (AS7740)	G
Acer	Aspire	Aspire 7741Z (AS7741Z)	G
Acer	Aspire	Aspire 9400 (AS9400)	G
Acer	Aspire	Aspire E1-572	G
Acer	Aspire	Aspire M5	G
Acer	Aspire	Aspire R7-571-N58G	G
Acer	Aspire	Aspire S3-951	G
Acer	Aspire	Aspire S7-392-F78U	G
Acer	Aspire	Aspire Timeline 3810T (AS3810T)	G
Acer	Aspire	Aspire Timeline 5810T (AS5810TG)	G
Acer	Aspire	Aspire V3	G
Acer	Aspire	Aspire V5	G
Acer	Aspire	Aspire V5-471	G
Acer	Aspire	Aspire V7-482P	G
Acer	Ferrari	Ferrari One 200 (FO200)	G
Acer	ICONIA	ICONIA W700D	G
Acer	TravelMate	TravelMate 3270 (TM3270)	G
Acer	TravelMate	TravelMate 4740 (TM4740)	G
Acer	TravelMate	TravelMate 5320 (TM5320)	G
Acer	TravelMate	TravelMate 5344 (TM5344)	G
Acer	TravelMate	TravelMate 5530 (TM5530)	G
Acer	TravelMate	TravelMate 5730 (TM5730)	G
Acer	TravelMate	TravelMate 5742Z (TM5742Z)	G

Acer	TravelMate	TravelMate 6292 (TM6292)	G
Acer	TravelMate	TravelMate 6493 (TM6493)	G
Acer	TravelMate	TravelMate 7530 (TM7530)	G
Acer	TravelMate	TravelMate 7750 (TM7750)	G
Acer	TravelMate	TravelMate 8371 (TM8371)	G
Acer	TravelMate	TravelMate 8471 (TM8471)	G
Acer	TravelMate	TravelMate 8571 (TM8571)	G
Acer	eMachines	eMachines D442	G
Acer	eMachines	eMachines D528	G
Acer	eMachines	eMachines D732Z	G
Acer	eMachines	eMachines E443	G
Acer	eMachines	eMachines E527	G
Acer	eMachines	eMachines E620	G
Acer	eMachines	eMachines E720	G
Acer	Aspire	Aspire One Cloudbook 11 AO1-131	L
Acer	Aspire	Aspire R13 R7-371T	L
Acer	Aspire	Aspire Switch 12 SW5-271	L
Acer	Aspire	Aspire V3-372T	L
Acer	Chromebook	Chromebook 14 CB3-531	L
Acer	Aspire	Aspire One Cloudbook 11 AO1-131	L
Acer	Aspire	Aspire R14 R5-471T	L
Acer	Aspire	Aspire V3-331	L
Acer	Chromebook	Chromebook 11 C730	L
Acer	Chromebook	Chromebook R 11 C738T	L
Acer	Aspire	Aspire One Cloudbook 11 AO1-431	L
Acer	Aspire	Aspire Switch 11 SW5-173	L
Acer	Aspire	Aspire V3-372	L
Acer	Chromebook	Chromebook 13 C830	L
Acer	Aspire	Aspire P3-131	L
Acer	Aspire	Aspire S7-191	L
Acer	Chromebook	Chromebook C720P	L
Acer	TravelMate	TravelMate X313-M	L
Acer	Aspire	Aspire P3-171	L
Acer	Aspire	Aspire S7-391	L
Acer	ICONIA	ICONIA W700	L
Acer	Aspire	Aspire S5-391	L
Acer	Chromebook	Chromebook C720	L
Acer	ICONIA	ICONIA W700P	L
Acer	Aspire	Aspire 1830Z (AS1830Z)	G
Acer	Aspire	Aspire E1-532-H14D/K	G
Acer	Aspire	Aspire E1-572-F54D/K	G
Acer	Aspire	Aspire E3-112-F14C/S	G
Acer	Aspire	Aspire ES1-511-A12C/F	G
Acer	Aspire	Aspire One 533 (AO533)	G
Acer	Aspire	Aspire One 756 (AO756)	G
Acer	Aspire	Aspire One D260 (AOD260)	G
Acer	Aspire	Aspire One Happy (AOHAPPY)	G
Acer	Aspire	Aspire V5-122P-N44D/S	G
Acer	Aspire	Aspire V5-131-N14D/S	G
Acer	Aspire	Aspire V5-171-H32D/S	G
Acer	Iconia	Iconia Tab W500p	G
Acer	TravelMate	TravelMate 8172Z (TM8172Z)	G
Acer	Aspire	Aspire E1-532-F14D/K	G
Acer	Aspire	Aspire E1-532-H14D/R	G
Acer	Aspire	Aspire E1-572P-F54F/K	G
Acer	Aspire	Aspire E5-571-A54G/K	G
Acer	Aspire	Aspire One 255E (AOD255E)	G

Acer	Aspire	Aspire One 722 (AO722)	G
Acer	Aspire	Aspire One D255 (AOD255)	G
Acer	Aspire	Aspire One D270 (AOD270)	G
Acer	Aspire	Aspire V5-122P	G
Acer	Aspire	Aspire V5-131	G
Acer	Aspire	Aspire V5-132P-F14D/S	G
Acer	Chromebook	Chromebook AC700	G
Acer	TravelMate	TravelMate 8172 (TM8172)	G
Acer	Aspire	Aspire E1-532-F14D/R	G
Acer	Aspire	Aspire E1-570-F34D/K	G
Acer	Aspire	Aspire E3-111-A14C/S	G
Acer	Aspire	Aspire ES1-511-A12C	G
Acer	Aspire	Aspire One 532 (AO532h)	G
Acer	Aspire	Aspire One 753 (AO753)	G
Acer	Aspire	Aspire One D257 (AOD257)	G
Acer	Aspire	Aspire One HAPPY2 (AOHAPPY2)	G
Acer	Aspire	Aspire V5-122P-A24D/S	G
Acer	Aspire	Aspire V5-131-N14D/R	G
Acer	Aspire	Aspire V5-171	G
Acer	Chromebook	Chromebook C710	G
Acer	Iconia	Iconia Tab W500	G
Acer	TravelMate	TravelMate 8172T (TM8172T)	G
Acer	Aspire	Aspire 1410 (AS1410)	G
Acer	Aspire	Aspire 1810TZ (AS1810TZ)	G
Acer	Aspire	Aspire One 752 (AO752)	G
Acer	Aspire	Aspire One D150 (AOD150)	G
Acer	Aspire	Aspire 1420P (AS1420P)	G
Acer	Aspire	Aspire One 531h (AO531h)	G
Acer	Aspire	Aspire One A110 (AOA110)	G
Acer	Aspire	Aspire One D250 (AOD250)	G
Acer	Aspire	Aspire 1810T (AS1810T)	G
Acer	Aspire	Aspire One 751 (AO751)	G
Acer	Aspire	Aspire One A150 (AOA150)	G
Acer	Aspire	Aspire One P531h (AOP531h)	G
Acer	Gateway	Gateway EC38	G
Acer	Gateway	Gateway ID47H	G
Acer	Gateway	Gateway ID58	G
Acer	Gateway	Gateway MC73	G
Acer	Gateway	Gateway MD26	G
Acer	Gateway	Gateway NE56	G
Acer	Gateway	Gateway NV40	G
Acer	Gateway	Gateway NV48	G
Acer	Gateway	Gateway NV51	G
Acer	Gateway	Gateway NV53	G
Acer	Gateway	Gateway NV55C	G
Acer	Gateway	Gateway NV57	G
Acer	Gateway	Gateway NV59	G
Acer	Gateway	Gateway NV73A	G
Acer	Gateway	Gateway NV78	G
Acer	Gateway	Gateway TC73	G
Acer	Gateway	Gateway TC79	G
Acer	Gateway	Gateway EC54	G
Acer	Gateway	Gateway ID49C	G
Acer	Gateway	Gateway ID59C	G
Acer	Gateway	Gateway MC78	G
Acer	Gateway	Gateway MD73	G
Acer	Gateway	Gateway NE570	G

Acer	Gateway	Gateway NV44(NV4400)	G
Acer	Gateway	Gateway NV49C	G
Acer	Gateway	Gateway NV51B	G
Acer	Gateway	Gateway NV53A	G
Acer	Gateway	Gateway NV55S	G
Acer	Gateway	Gateway NV57H	G
Acer	Gateway	Gateway NV59C	G
Acer	Gateway	Gateway NV75S	G
Acer	Gateway	Gateway NV79	G
Acer	Gateway	Gateway TC74	G
Acer	Gateway	Gateway EC58(EC5800)	G
Acer	Gateway	Gateway ID57H	G
Acer	Gateway	Gateway LT32	G
Acer	Gateway	Gateway MD24	G
Acer	Gateway	Gateway MD78	G
Acer	Gateway	Gateway NE572	G
Acer	Gateway	Gateway NV47H	G
Acer	Gateway	Gateway NV50A	G
Acer	Gateway	Gateway NV52	G
Acer	Gateway	Gateway NV54	G
Acer	Gateway	Gateway NV56	G
Acer	Gateway	Gateway NV58	G
Acer	Gateway	Gateway NV73	G
Acer	Gateway	Gateway NV77H	G
Acer	Gateway	Gateway NV79C	G
Acer	Gateway	Gateway TC78	G
Acer	Gateway	Gateway EC19C	G
Acer	Gateway	Gateway LT23	G
Acer	Gateway	Gateway LT21 (LT2100)	G
Acer	Gateway	Gateway LT28	G
Acer	Gateway	Gateway LT22	G
Acer	Gateway	Gateway 250	G
Acer	Gateway	Gateway EC18	G
Acer	Gateway	Gateway LT25	G
Acer	Gateway	Gateway LT31	G
Acer	Gateway	Gateway EC14	G
Acer	Gateway	Gateway LT10	G
Acer	Gateway	Gateway LT27	G
Acer	Gateway	Inspiron 1210	G
Acer	Gateway	Gateway EC14D	G
Acer	Gateway	Gateway LT20	G
Acer	Gateway	Gateway LT30	G
Acer	Gateway	Gateway 250	G
Acer	Gateway	Gateway EC18	G
Acer	Gateway	Gateway LT25	G
Acer	Gateway	Gateway LT31	G